

and a push-pull output. The two amplifiers share common

supplies but otherwise operate independently. Linearizing

diodes are provided at the inputs to reduce distortion and

allow higher input levels. The result is a 10 dB signal-to-

noise improvement referenced to 0.5 percent THD. High impedance buffers are provided which are especially designed

to complement the dynamic range of the amplifiers. The

output buffers of the LM13700 differ from those of the

LM13600 in that their input bias currents (and hence their output DC levels) are independent of $I_{ABC}.$ This may result in performance superior to that of the LM13600 in audio

LM13700/LM13700A Dual Operational Transconductance Amplifiers with Linearizing Diodes and Buffers

General Description

Features


- The LM13700 series consists of two current controlled transconductance amplifiers, each with differential inputs Excellent g_m linearity
 - Excellent g_m linearity
 Excellent matching between emplified
 - Excellent matching between amplifiers
 - Linearizing diodes
 - High impedance buffers
 - High output signal-to-noise ratio

Applications

- Current-controlled amplifiers
- Current-controlled impedances
- Current-controlled filters
- Current-controlled oscillators
- Multiplexers
- Timers
- Sample-and-hold circuits

Connection Diagram

applications.



© 1995 National Semiconductor Corporation TL/H/7981

RRD-B30M115/Printed in U. S. A.

November 1994

with Linearizing Diodes and Buffers

.M13700/LM13700A Dual Operational Transconductance Amplifiers

Absolute Maximum Ratings If Military/Aerospace specified devices are required, please contact the National Semiconductor Sales Operating Temperature Range LM13700N, LM13700AN $0^{\circ}C$ to $+70^{\circ}C$ Office/Distributors for availability and specifications. DC Input Voltage $+V_{S}$ to $-V_{S}$ Supply Voltage (Note 1) Storage Temperature Range -65°C to +150°C LM13700 36 $V_{DC}\,or\,\pm18V$ Soldering Information LM13700A 44 V_{DC} or \pm 22V Dual-In-Line Package Power Dissipation (Note 2) $T_{A}=25^{\circ}\text{C}$ LM13700N, LM13700AN Soldering (10 sec.) 260°C 570 mW Small Outline Package Differential Input Voltage $\pm 5V$ Vapor Phase (60 sec.) 215°C Infrared (15 sec.) 220°C Diode Bias Current (I_D) 2 mA Amplifier Bias Current (IABC) See AN-450 "Surface Mounting Methods and Their Effect 2 mA on Product Reliability" for other methods of soldering sur-Output Short Circuit Duration Continuous face mount devices.

20 mA

Electrical Characteristics (Note 4)

Buffer Output Current (Note 3)

Parameter	Conditions		LM13700)	LM13700A			11
		Min	Тур	Max	Min	Тур	Max	Units
Input Offset Voltage (V _{OS})	Over Specified Temperature Range		0.4	4		0.4	1 2	mV
	$I_{ABC} = 5 \ \mu A$		0.3	4		0.3	1	
V _{OS} Including Diodes	Diode Bias Current (I _D) = 500 μ A		0.5	5		0.5	2	mV
Input Offset Change	$5 \ \mu A \leq I_{ABC} \leq 500 \ \mu A$		0.1	3		0.1	1	mV
Input Offset Current			0.1	0.6		0.1	0.6	μA
Input Bias Current	Over Specified Temperature Range		0.4	5		0.4	5	μΑ
			1	8		1	7	
Forward Transconductance (g _m)		6700	9600	13000	7700	9600	12000	μmhc
	Over Specified Temperature Range	5400			4000			
g _m Tracking			0.3			0.3		dB
Peak Output Current	$R_L = 0, I_{ABC} = 5 \mu A$		5		3	5	7	μΑ
	R _L = 0, I _{ABC} = 500 μA	350	500	650	350	500	650	
	$R_L = 0$, Over Specified Temp Range	300			300			
Peak Output Voltage								
Positive	$R_{L}=~\infty,5~\muA\leqI_{ABC}\leq500~\muA$	+ 12	+14.2		+12	+14.2		l v
Negative	$R_L = \infty, 5 \ \mu A \le I_{ABC} \le 500 \ \mu A$	-12	-14.4		-12	-14.4		V
Supply Current	$I_{ABC} = 500 \ \mu A$, Both Channels		2.6			2.6		mA
V _{OS} Sensitivity Positive Negative	$\Delta V_{OS} / \Delta V^+ \\ \Delta V_{OS} / \Delta V^-$		20 20	150 150		20 20	150 150	μV/ μV/
CMRR		80	110		80	110		dB
Common Mode Range		±12	±13.5		±12	±13.5		v
Crosstalk	Referred to Input (Note 5) 20 Hz < f < 20 kHz		100			100		dB
Differential Input Current	$I_{ABC} = 0$, Input = $\pm 4V$		0.02	100		0.02	10	nA
Leakage Current	I _{ABC} = 0 (Refer to Test Circuit)		0.2	100		0.2	5	nA
Input Resistance		10	26		10	26		kΩ

Electrical Characteristics (Note 4) (Continued)												
Parameter	Conditions	LM13700			LM13700A							
		Min	Тур	Мах	Min	Тур	Max	Units				
Open Loop Bandwidth			2			2		MHz				
Slew Rate	Unity Gain Compensated		50			50		V/µs				
Buffer Input Current	(Note 5)		0.5	2		0.5	2	μA				
Peak Buffer Output Voltage	(Note 5)	10			10			v				

Note 1: For selections to a supply voltage above $\pm 22V$, contact factory.


Note 2: For operation at ambient temperatures above 25°C, the device must be derated based on a 150°C maximum junction temperature and a thermal resistance, junction to ambient, as follows: LM13700N, 90°C/W; LM13700N, 110°C/W.

Note 3: Buffer output current should be limited so as to not exceed package dissipation.


Note 4: These specifications apply for $V_S = \pm 15V$, $T_A = 25^{\circ}C$, amplifier bias current (I_{ABC}) = 500 μ A, pins 2 and 15 open unless otherwise specified. The inputs to the buffers are grounded and outputs are open.


Note 5: These specifications apply for V_S = \pm 15V, I_{ABC} = 500 μ A, R_{OUT} = 5 k Ω connected from the buffer output to $-V_S$ and the input of the buffer is connected to the transconductance amplifier output.

Schematic Diagram



TL/H/7981-1





Circuit Description

The differential transistor pair Q_4 and Q_5 form a transconductance stage in that the ratio of their collector currents is defined by the differential input voltage according to the transfer function:

$$V_{\rm IN} = \frac{\rm kT}{\rm q} \, \ln \, \frac{\rm l_5}{\rm l_4} \tag{1}$$

where V_{IN} is the differential input voltage, kT/q is approximately 26 mV at 25°C and I_5 and I_4 are the collector currents of transistors Q_5 and Q_4 respectively. With the exception of Q_3 and Q_{13} , all transistors and diodes are identical in size. Transistors Q_1 and Q_2 with Diode D_1 form a current mirror which forces the sum of currents I_4 and I_5 to equal I_{ABC} :

$$I_4 + I_5 = I_{ABC} \tag{2}$$

where $I_{\mbox{ABC}}$ is the amplifier bias current applied to the gain pin.

For small differential input voltages the ratio of I_4 and I_5 approaches unity and the Taylor series of the In function can be approximated as:

$$\begin{array}{l} \frac{kT}{q} \ \ln \frac{l_5}{l_4} \approx \frac{kT}{q} \frac{l_5 - l_4}{l_4} \\ l_4 \approx l_5 \approx \frac{l_{ABC}}{2} \\ V_{IN} \left[\frac{l_{ABC}q}{2kT} \right] = l_5 - l_4 \end{array} \tag{3}$$

Collector currents I_4 and I_5 are not very useful by themselves and it is necessary to subtract one current from the other. The remaining transistors and diodes form three current mirrors that produce an output current equal to I_5 minus I_4 thus:

$$V_{IN} \left[\frac{I_{ABC}^{q}}{2kT} \right] = I_{OUT}$$
(5)

The term in brackets is then the transconductance of the amplifier and is proportional to $I_{\mbox{ABC}}.$

Linearizing Diodes

For differential voltages greater than a few millivolts, Equation 3 becomes less valid and the transconductance becomes increasingly nonlinear. *Figure 1* demonstrates how the internal diodes can linearize the transfer function of the amplifier. For convenience assume the diodes are biased with current sources and the input signal is in the form of current I_S. Since the sum of I₄ and I₅ is I_{ABC} and the difference is I_{OUT}, currents I₄ and I₅ can be written as follows:

$$I_4 = \frac{I_{ABC}}{2} - \frac{I_{OUT}}{2}, I_5 = \frac{I_{ABC}}{2} + \frac{I_{OUT}}{2}$$


Since the diodes and the input transistors have identical geometries and are subject to similar voltages and temperatures, the following is true:

$$\frac{kT}{q} \ln \frac{\frac{lD}{2} + lS}{\frac{lD}{2} - lS} = \frac{kT}{q} \ln \frac{\frac{lABC}{2} + \frac{lOUT}{2}}{\frac{lABC}{2} - \frac{lOUT}{2}}$$
$$\therefore l_{OUT} = l_{S} \left(\frac{2l_{ABC}}{l_{D}}\right) \text{ for } |l_{S}| < \frac{lD}{2}$$
(6)

Notice that in deriving Equation 6 no approximations have been made and there are no temperature-dependent terms. The limitations are that the signal current not exceed $I_D/2$ and that the diodes be biased with currents. In practice, replacing the current sources with resistors will generate insignificant errors.

Applications: Voltage Controlled Amplifiers

Figure 2 shows how the linearizing diodes can be used in a voltage-controlled amplifier. To understand the input biasing, it is best to consider the 13 k Ω resistor as a current source and use a Thevenin equivalent circuit as shown in Figure 3. This circuit is similar to Figure 1 and operates the same. The potentiometer in Figure 2 is adjusted to minimize the effects of the control signal at the output.



Applications: Voltage Controlled Amplifiers (Continued)

For optimum signal-to-noise performance, $I_{\mbox{ABC}}$ should be as large as possible as shown by the Output Voltage vs. Amplifier Bias Current graph. Larger amplitudes of input signal also improve the S/N ratio. The linearizing diodes help here by allowing larger input signals for the same output distortion as shown by the Distortion vs. Differential Input Voltage graph. S/N may be optimized by adjusting the magnitude of the input signal via RIN (Figure 2) until the output

distortion is below some desired level. The output voltage swing can then be set at any level by selecting RL.

Although the noise contribution of the linearizing diodes is negligible relative to the contribution of the amplifier's internal transistors, ID should be as large as possible. This minimizes the dynamic junction resistance of the diodes (r_e) and maximizes their linearizing action when balanced against $R_{\text{IN}}.$ A value of 1 mA is recommended for I_{D} unless the specific application demands otherwise.




FIGURE 3. Equivalent VCA Input Circuit

Stereo Volume Control


The circuit of *Figure 4* uses the excellent matching of the two LM13700 amplifiers to provide a Stereo Volume Control with a typical channel-to-channel gain tracking of 0.3 dB. Rp is provided to minimize the output offset voltage and may be replaced with two 510 Ω resistors in AC-coupled applications. For the component values given, amplifier gain is derived for *Figure 2* as being:

 $\frac{V_O}{V_{IN}}=940\times I_{ABC}$

If V_C is derived from a second signal source then the circuit becomes an amplitude modulator or two-quadrant multiplier as shown in *Figure 5*, where:

$$I_{O} = \frac{-2I_{S}}{I_{D}}(I_{ABC}) = \frac{-2I_{S}}{I_{D}}\frac{V_{IN2}}{R_{C}} - \frac{2I_{S}}{I_{D}}\frac{(V^{-} + 1.4V)}{R_{C}}$$

The constant term in the above equation may be cancelled by feeding $I_S \times I_D R_C/2(V^- + 1.4V)$ into I_O . The circuit of *Figure 6* adds R_M to provide this current, resulting in a fourquadrant multiplier where R_C is trimmed such that $V_O = 0V$ for $V_{IN2} = 0V$. R_M also serves as the load resistor for I_O .



Stereo Volume Control (Continued)




FIGURE 6. Four-Quadrant Multiplier

Noting that the gain of the LM13700 amplifier of *Figure 3* may be controlled by varying the linearizing diode current I_D as well as by varying I_{ABC} , *Figure 7* shows an AGC Amplifier using this approach. As V_O reaches a high enough amplitude $(3V_{BE})$ to turn on the Darlington transistors and the linearizing diodes, the increase in I_D reduces the amplifier gain so as to hold V_O at that level.


to the LM13700 which is then multiplied by the $\rm g_m$ of the amplifier to produce an output current, thus:


$$R_{X} = \frac{R + R_{A}}{g_{m} R_{A}}$$

where $g_m\approx 19.2I_{ABC}$ at 25°C. Note that the attenuation of V_O by R and R_A is necessary to maintain V_{IN} within the linear range of the LM13700 input.

Voltage Controlled Resistors

An Operational Transconductance Amplifier (OTA) may be used to implement a Voltage Controlled Resistor as shown in *Figure 8*. A signal voltage applied at R_X generates a V_{IN} *Figure 9* shows a similar VCR where the linearizing diodes are added, essentially improving the noise performance of the resistor. A floating VCR is shown in *Figure 10*, where each "end" of the "resistor" may be at any voltage within the output voltage range of the LM13700.







Voltage Controlled Filters

OTA's are extremely useful for implementing voltage controlled filters, with the LM13700 having the advantage that the required buffers are included on the I.C. The VC Lo-Pass Filter of *Figure 11* performs as a unity-gain buffer amplifier at frequencies below cut-off, with the cut-off frequency being the point at which X_C/g_m equals the closed-loop gain of (R/R_A). At frequencies above cut-off the circuit provides a single RC roll-off (6 dB per octave) of the input signal amplitude with a -3 dB point defined by the given equation, where g_m is again 19.2 \times I_{ABC} at room temperature. *Figure*

12 shows a VC High-Pass Filter which operates in much the same manner, providing a single RC roll-off below the defined cut-off frequency.

Additional amplifiers may be used to implement higher order filters as demonstrated by the two-pole Butterworth Lo-Pass Filter of *Figure 13* and the state variable filter of *Figure 14*. Due to the excellent g_m tracking of the two amplifiers, these filters perform well over several decades of frequency.






Voltage Controlled Oscillators


The classic Triangular/Square Wave VCO of *Figure 15* is one of a variety of Voltage Controlled Oscillators which may be built utilizing the LM13700. With the component values shown, this oscillator provides signals from 200 kHz to below 2 Hz as I_C is varied from 1 mA to 10 nA. The output amplitudes are set by I_A × R_A. Note that the peak differential input voltage must be less than 5V to prevent zenering the inputs.

A few modifications to this circuit produce the ramp/pulse VCO of Figure 16. When V_{O2} is high, I_F is added to I_C to

increase amplifier A1's bias current and thus to increase the charging rate of capacitor C. When V_{O2} is low, I_F goes to zero and the capacitor discharge current is set by $I_C.$

The VC Lo-Pass Filter of *Figure 11* may be used to produce a high-quality sinusoidal VCO. The circuit of *Figure 16* employs two LM13700 packages, with three of the amplifiers configured as lo-pass filters and the fourth as a limiter/inverter. The circuit oscillates at the frequency at which the loop phase-shift is 360° or 180° for the inverter and 60° per filter stage. This VCO operates from 5 Hz to 50 kHz with less than 1% THD.









FIGURE 18. Single Amplifier VCO

Figure 18 shows how to build a VCO using one amplifier when the other amplifier is needed for another function.


Figure 19 presents an interesting one-shot which draws no power supply current until it is triggered. A positive-going trigger pulse of at least 2V amplitude turns on the amplifier through R_B and pulls the non-inverting input high. The amplifier regenerates and latches its output high until capacitor C charges to the voltage level on the non-inverting input. The output then switches low, turning off the amplifier and discharging the capacitor. The capacitor discharge rate is speeded up by shorting the diode bias pin to the inverting input so that an additional discharge current flows through D_I when the amplifier output switches low. A special feature of this timer is that the other amplifier, when biased from V_O , can perform another function and draw zero stand-by power as well.



Additional Applications (Continued)

The operation of the multiplexer of *Figure 20* is very straightforward. When A1 is turned on it holds V_O equal to V_{IN1} and when A2 is supplied with bias current then it controls V_O. C_C and R_C serve to stabilize the unity-gain configuration of amplifiers A1 and A2. The maximum clock rate is limited to about 200 kHz by the LM13700 slew rate into 150 pF when the (V_{IN1}-V_{IN2}) differential is at its maximum allowable value of 5V.

The Phase-Locked Loop of *Figure 21* uses the four-quadrant multiplier of *Figure 6* and the VCO of *Figure 18* to produce a PLL with a $\pm 5\%$ hold-in range and an input sensitivity of about 300 mV.



Additional Applications (Continued)

The Schmitt Trigger of *Figure 22* uses the amplifier output current into R to set the hysteresis of the comparator; thus $V_H = 2 \times R \times I_B$. Varying I_B will produce a Schmitt Trigger with variable hysteresis.





Figure 23 shows a Tachometer or Frequency-to-Voltage converter. Whenever A1 is toggled by a positive-going input, an amount of charge equal to $(V_H - V_D) C_t$ is sourced into C_f and R_t . This once per cycle charge is then balanced by the current of V_O/R_t . The maximum F_{IN} is limited by the amount of time required to charge C_t from V_L to V_H with a current of I_B , where V_L and V_H represent the maximum low and maximum high output voltage swing of the LM13700. D1 is added to provide a discharge path for C_t when A1 switches low. The Peak Detector of *Figure 24* uses A2 to turn on A1 whenever V_{IN} becomes more positive than V_O . A1 then charges storage capacitor C to hold V_O equal to V_{IN} PK. Pulling the output of A2 low through D1 serves to turn off A1 so that V_O remains constant.

-0

TL/H/7981-31



TL/H/7981-29



Additional Applications (Continued)


The Ramp-and-Hold of Figure 26 sources IB into capacitor C whenever the input to A1 is brought high, giving a ramprate of about 1V/ms for the component values shown.

The true-RMS converter of Figure 27 is essentially an automatic gain control amplifier which adjusts its gain such that the AC power at the output of amplifier A1 is constant. The output power of amplifier A1 is monitored by squaring amplifier A2 and the average compared to a reference voltage with amplifier A3. The output of A3 provides bias current to the diodes of A1 to attenuate the input signal. Because the output power of A1 is held constant, the RMS value is constant and the attenuation is directly proportional to the RMS value of the input voltage. The attenuation is also proportional to the diode bias current. Amplifier A4 adjusts the ratio of currents through the diodes to be equal and therefore the voltage at the output of A4 is proportional to the RMS value of the input voltage. The calibration potentiometer is set such that V_O reads directly in RMS volts.

+15 V

-15 V

___^{+ 5} V






FIGURE 27. True RMS Converter

The circuit of *Figure 28* is a voltage reference of variable Temperature Coefficient. The 100 k Ω potentiometer adjusts the output voltage which has a positive TC above 1.2V, zero TC at about 1.2V, and negative TC below 1.2V. This is accomplished by balancing the TC of the A2 transfer function against the complementary TC of D1.

The wide dynamic range of the LM13700 allows easy control of the output pulse width in the Pulse Width Modulator of *Figure 29*.

For generating I_{ABC} over a range of 4 to 6 decades of current, the system of *Figure 30* provides a logarithmic current out for a linear voltage in.

Since the closed-loop configuration ensures that the input to A2 is held equal to 0V, the output current of A1 is equal to $I_3 = -V_C/R_C$.

The differential voltage between Q1 and Q2 is attenuated by the R1,R2 network so that A1 may be assumed to be operating within its linear range. From equation (5), the input voltage to A1 is:

$$V_{IN}1 = \frac{-2kTI_3}{qI_2} = \frac{-2kTV_C}{qI_2R_C}$$

The voltage on the base of Q1 is then

$$V_{\rm B} 1 = \frac{(R_1 + R_2) V_{\rm IN}}{R_1}$$

The ratio of the Q1 and Q2 collector currents is defined by:


$${}_{B}1 = \frac{kT}{q} \ln \frac{l_{C2}}{l_{C1}} \approx \frac{kT}{q} \ln \frac{l_{ABC}}{l_{1}}$$


Combining and solving for IABC yields:


V


$$I_{ABC} = I_1 \exp \frac{2(R_1 + R_2) V_C}{R_1 I_2 R_C}$$

This logarithmic current can be used to bias the circuit of *Figure 4* to provide temperature independent stereo attenuation characteristic.









National does not assume any responsibility for use of any circuitry described, no circuit patent licenses are implied and National reserves the right at any time without notice to change said circuitry and specifications